# ECLine

NOTEBOOK LOCK

EC-CP002

FEATURES:

1. Key lock: no need to remember personal combinations and worry about forgetting own combinations.
2. Easy to use.
3. Mini design and Portable.

INSTRUCTION:

The preset status is locked.
The gap of inner cylinder stays on the gap (B).

HOW TO UNLOCK /LOCK:

1.HOW TO UNLOCK:

STEP 1:

Insert the key into the gap (B) and push the cylinder inward.


STEP 2:

Immediately, rotate 90? to the right till the gap (A).
The lock is unlocked.
(Note: When the lock is unlocked, the key can not pull out anymore.)

2.HOW TO LOCK:

STEP 1:

Find an object (e.g. table) to secure the lock and then put the lock through the cable loop.

STEP 2:

Keep the key staying on the gap (A) and insert the lock into the computer slot. Continuously, push the cylinder inward and then rotate 90? to the left till the gap (B). Release the key from the gap (B). The lock is locked.
(Note: Please make sure that the key is stored carefully after finish using. Prevent the key from being lost)